
Assembly Instructions

Jorgenson Kids Sports Locker



Identify Parts

Remove unassembled locker parts from the packaging. Next, locate and identify each part based on the images show below:

TIP: Tip: Ensure that the bolts are installed on the outside of locker and nuts are secured on the inside of the locker.








Top/Bottom are identical




(1) Hat Shelf












Start Assembling

- Position the back panel on straight, even flooring or pair of saw horses.
- Gently bolt the left and right side panel to the inside of each back panel



View of locker with back panel flat on floor or saw horses

The left and right side panels must be placed inside the back panel flanges. Side Panels → ← Back Panel




Assembly Instructions

Jorgenson Kids Sports Locker

• 3 •

Continued Assembly

• Slightly bolt the top panel, hat shelf, and bottom panel inside the side and back panel.




Note:

Top and bottom panels have two (2) round, pre-drilled holes that can be found on the back flange and are designed to bolt to the back panel.

• **4** •

Insert Front Door Frame

 After the top and bottom panels have been attached, proceed to insert the door frame on the outside of the left, right and bottom panels.





Assembly Instructions

Jorgenson Kids Sports Locker

• 5 •

Insert Front Door Frame

- Place locker in the upright position and make sure locker is level.
- When locker is level, test the door to determine it opens properly. Bolts can be adjusted if there are any problems with opening and closing.
- Once the door is functioning correctly, tighten all bolts.
- To instill proper safety measures, we highly advise anchoring the locker to the floor or wall to avoid injury or theft.

